
























Insignia & Dynex TV Codes for Universal Remote Controls (Updated Feb 8, 2008)				UNIVERSAL REMOTE CONTROL MAKE AND MODEL				SET TOP BOX REMOTE MAKE AND MODEL							NOTES	
				Philips	RCA	One For All	SONY	COMCAST	DIRECTV	DISH NETWORK	MOTOROLA	TIVO	CHARTER	CABLEVISION		COX
Insignia TV Model No.	TV Type	Best Buy Part No.	INSIGNIA TV View	Recommended Model: PHILIPS: RMK005, RMK006, RMK007	Recommended Model: RCA: RCU807	Recommended Model: URC: 6699	Recommended Model: RM: RM-600	Model: M1057	Model: RC23	Models: VPS06, VPS22	Model: DRC800	Model: SERIES 3, HD	Model: Charter Digital	Model: UR2-CBL-CV54	Model: COX	
<b>ALL INSIGNIA &amp; DYNEX TV MANUFACTURED AFTER JAN 1, 2007</b>				115	135	0464	8043	0463, 10463	10463	720	0463	0091	0463	096	0463	For compatibility with other universal remotes, use codes listed for these brands: Orion, Emerson, Memorex, Sansui, Sylvania, Zenith
IS-TV04917	13" Round CRT TV	7017596		115	135	0463	8042	0463, 10463	10463	720	0463	0091	0463	096	0463	For compatibility with other universal remotes, use codes listed for these brands: Orion, Emerson, Memorex, Sansui, Sylvania, Zenith
NS-13CTV	13" CRT TV/DVD COMBO	7600848		020	062	0783	Use Code Search	Use Code Search	10783	Use Code Search	Use Code Search	Use Code Search	Use Code Search	Use Code Search	Use Code Search	Codes listed are for TV Functions Only
NS-14CFT	14" Combo Flat CRT TV	7801446		115	135	0463	8042	0463, 10463	10463	720	0463	0091	0463	096	0463	Only for TVs with manufacture date of July 2006 or later. Must use Learn Mode of Universal Remote for TVs manufactured before July 2006. Codes listed are for TV Functions Only.
NS-14FTV	14" Flat CRT TV	7600982		115	135	0463	8042	0463, 10463	10463	720	0463	0091	0463	096	0463	Only for TVs with manufacture date of July 2006 or later. Must use Learn Mode of Universal Remote for TVs manufactured before July 2006.
NS-19LCD	19" LCD TV	7861833		115	135	0463	8042	0463, 10463	10463	720	0463	0091	0463	096	0463	For compatibility with other universal remotes, use codes listed for these brands: Orion, Emerson, Memorex, Sansui, Sylvania, Zenith
NS-19RTR	19" Triple Combo Round CRT TV	7600456		247	198, 231	1944	Use Code Search	Use Code Search	11944	Use Code Search	Use Code Search	Use Code Search	Use Code Search	Use Code Search	Use Code Search	Codes listed are for TV Functions Only
NS-20FTV	20" Flat CRT TV	7601008		115	135	0463	8042	0463, 10463	10463	720	0463	0091	0463	096	0463	Only for TVs with manufacture date of July 2006 or later. Must use Learn Mode of Universal Remote for TVs manufactured before July 2006.
IS-TV04919	20" Round CRT TV	7005787		115	135	0463	8042	0463, 10463	10463	720	0463	0091	0463	096	0463	Only for TVs with manufacture date of July 2006 or later. Must use code search of Learn Mode of Universal Remote for TVs manufactured before July 2006.
IS-TV0V020	20" CRT TV/DVD COMBO	7279081		020	062	0783	Use Code Search	Use Code Search	10783	Use Code Search	Use Code Search	Use Code Search	Use Code Search	Use Code Search	Use Code Search	Codes listed are for TV Functions Only
NS-20CLTV	20" LCD TV Combo	7844256		Use Learn Mode	Use Learn Mode	Use Learn Mode	Use Learn Mode	Use Code Search	Use Learn Mode	Use Code Search	Use Code Search	Use Code Search	Use Code Search	Use Code Search	Use Code Search	Must use Learn Mode of Universal Remote.
NS-20LCD	20" LCD TV	7784828		807	163	Use Code Search	8043	Use Code Search	Use Code Search	Use Code Search	Use Code Search	Use Code Search	Use Code Search	Use Code Search	Use Code Search	For compatibility with other universal remotes, perform code search.
IS-TV04922A	24" Round CRT TV	7006038		115	135	0463	8042	0463, 10463	10463	720	0463	0091	0463	096	0463	Only for TVs with manufacture date of July 2006 or later. Must use Learn Mode of Universal Remote for TVs manufactured before July 2006.
NS-24FTV	24" Flat CRT TV	7601026		115	135	0463	8042	0463, 10463	10463	720	0463	0091	0463	096	0463	For compatibility with other universal remotes, use codes listed for these brands: Orion, Emerson, Memorex, Sansui, Sylvania, Zenith
IS-LCDTV26	26" LCD TV	7070705		102	005	1250	8024	0093, 0150, 0178	11250	-	0093, 0150, 0178	-	0093, 0150, 0178	109, 024, 042, 004, 040, 146, 028, 232, 255, 081, 200	0093, 0150, 0178	For compatibility with other universal remotes, use codes listed for Mitsubishi TV.
NS-27RTV	27" Round CRT SD TV	7601838		115	135	0463	8042	0463, 10463	10463	720	0463	0091	0463	096	0463	For compatibility with other universal remotes, use codes listed for these brands: Orion, Emerson, Memorex, Sansui, Sylvania, Zenith
NS-FTV27	27" Flat CRT SD TV	7684972		115	135	0463	8042	0463, 10463	10463	720	0463	0091	0463	096	0463	For compatibility with other universal remotes, use codes listed for these brands: Orion, Emerson, Memorex, Sansui, Sylvania, Zenith
NS-27HDTV	27" Flat CRT HDTV	7601491		Use Learn Mode	Use Learn Mode	Use Learn Mode	Use Learn Mode	-	Use Learn Mode	-	-	-	-	-	-	Must use Learn Mode of Universal Remote.
NS-27LCD	27" LCD HDTV	7867338		115	135	0463	8042	0463, 10463	10463	720	0463	0091	0463	096	0463	For compatibility with other universal remotes, use codes listed for these brands: Orion, Emerson, Memorex, Sansui, Sylvania, Zenith
NS-30HDTV	30" Flat CRT HDTV	7600955		115	135	0463	8042	0463, 10463	10463	720	0463	0091	0463	096	0463	For compatibility with other universal remotes, use codes listed for these brands: Orion, Emerson, Memorex, Sansui, Sylvania, Zenith
NS-RTV32	32" Round CRT SD TV	7685007		115	135	0463	8042	0463, 10463	10463	720	0463	0091	0463	096	0463	For compatibility with other universal remotes, use codes listed for these brands: Orion, Emerson, Memorex, Sansui, Sylvania, Zenith
NS-32LCD	32" LCD HDTV	7975621		115	135	0463	8042	0463, 10463	10463	720	0463	0091	0463	096	0463	For compatibility with other universal remotes, use codes listed for these brands: Orion, Emerson, Memorex, Sansui, Sylvania, Zenith
IS-LCDTV32	32" LCD TV	7070484		102	005	1250	8024	0093, 0150, 0178	11250	-	0093, 0150, 0178	-	0093, 0150, 0178	109, 024, 042, 004, 040, 146, 028, 232, 255, 081, 200	0093, 0150, 0178	For compatibility with other universal remotes, use codes listed for Mitsubishi TV.
NS-42PPD	42" Plasma HDTV	7865465		115	135	0463	8042	0463, 10463	10463	720	0463	0091	0463	096	0463	For compatibility with other universal remotes, use codes listed for these brands: Orion, Emerson, Memorex, Sansui, Sylvania, Zenith